

TROUBLESHOOTING GUIDE	7. Connect the BT devices
<p>The copyrighted content from Hulu, Netflix, and similar services cannot be mirrored or cast.</p> <p>The projector offers a range of officially licensed streaming apps. You can get to the <b>Homepage</b> App, search for the app, download it and log into it to access you to play the content. For casting, refer to the <b>GOOGLE CAST</b> section.</p>	<p>↳ Go to <b>Homepage</b> - Dashboard ⚙️ - All settings ⚙️ - <b>Remotes &amp; Accessories</b> to check the BT device list, and connect the device.</p>
<p><b>2. Fixing Image</b></p> <ul style="list-style-type: none"> <li>Adjust the focus of the projector.</li> <li>Make sure the projector distance is in the effective focal range of the projector.</li> <li>Remove the dust or dirt from the lens with a clean and soft-bristled brush.</li> </ul>	<p><b>8. Power adapter getting warm</b></p> <p>It's normal for the power adapter to become hot during use. It's been tested and meets safety standards. Rest assured.</p>
<p><b>3. Fixing Image</b></p> <ul style="list-style-type: none"> <li>Adjust the focus of the projector.</li> <li>Make sure the projector distance is in the effective focal range of the projector.</li> <li>Remove the dust or dirt from the lens with a clean and soft-bristled brush.</li> </ul>	<p><b>9. No video audio output when using BT7</b></p> <p>In order to get rid of this lag, we suggest you turn your device to the projector via a wired connection. Additionally, please make sure your BT device closer to the projector in order to minimize interference in the environment.</p>
<p><b>3. Non-rectangular image</b></p> <ul style="list-style-type: none"> <li>Please place the projector perpendicular to the screen/wall. If the keystone correction function is not used.</li> <li>Use the keystone correction function to adjust the image shape.</li> </ul>	<p><b>10. Warm air blowing from the projector's vents</b></p> <p>The projector vents warm air as part of its normal cooling process to prevent overheating and maintain optimal performance.</p>
<p><b>4. Automatic keystone correction failure</b></p> <ul style="list-style-type: none"> <li>Make sure the adjustment sensor on the front of the projector is not blocked or smudged.</li> <li>The projector supports 120° vertical and horizontal keystone correction. Do not tilt the projector too much.</li> </ul>	<p><b>11. Others</b></p> <ul style="list-style-type: none"> <li>Please feel free to contact us at email.</li> </ul>
<p><b>5. Antiofuse failure</b></p> <ul style="list-style-type: none"> <li>Make sure the adjustment sensor on the front of the projector is not blocked or smudged.</li> <li>Make the projector back and forth, and use the projector in its recommended perspective.</li> </ul>	<p><b>READ BEFORE USE</b></p> <p>Please read the <b>Product Instructions</b> carefully.</p> <p>Thank you for purchasing and using this product.</p> <p>For your safety and interests, please read the <b>Product Instructions</b> carefully before using the product.</p>
<p><b>6. Remote control unresponsive</b></p> <ul style="list-style-type: none"> <li>Make sure the batteries are installed correctly and not drained.</li> <li>Remove any obstructions between your projector and remote control.</li> <li>Ensure the remote control is successfully paired with projector as BT.</li> <li>Make sure the button is pressed or struck and the power indicator is still on. If yes, please contact customer support or local service center.</li> </ul>	<p><b>About the Product Instructions:</b></p> <p>The trademarks and names mentioned in the Product Instructions are the property of their respective owners.</p> <p>All Product Instructions are powered by the Product Instructions only. The actual product may vary due to product enhancements.</p> <p>We shall not be liable for any personal injury, property damage, or other damages caused by the failure of the user to comply with the Product Instructions or precautions.</p>
<p><b>7. Fixing Image</b></p> <ul style="list-style-type: none"> <li>Adjust the focus of the projector.</li> <li>Make sure the projector distance is in the effective focal range of the projector.</li> <li>Remove the dust or dirt from the lens with a clean and soft-bristled brush.</li> </ul>	<p><b>Aurzen reserves the right to interpret and modify the Product Instructions.</b></p>

Support@Aurzen.com

Support@Aurzen.com 22

